


Vista and Windows 7: Disabling UAC (User Account Control)


Before installing VisiLogic, disable UAC as described below. If you have already installed VisiLogic, you may need to uninstall and reinstall it as described on page 2.

Disabling UAC in Windows 7

1. Type UAC into the Start Menu or Control Panel search box.




2. Drag the slider bar completely down to "Never notify" to disable it entirely, and then click OK.



Disabling UAC in Vista

1. Open up the Control Panel and type UAC into the search box.



2. Uncheck the box for "Use User Account Control (UAC)", and then click OK.



Re-installing VisiLogic

1. Back up all projects.
2. Uninstall VisiLogic, as well as other Unitronics software
3. Delete the folder "Unitronics VisiLogic_C" from C:\Program Files\Unitronics
4. Delete the folder "Unitronics" from C:\Program Files\Common Files
5. Reboot the PC.
6. Install VisiLogic.